



## Type 14

### Seismic Rod Brace Clamps

---

Seismic Rod Brace Clamps shall be capable of increasing the buckling allowable of the suspended rod when the applied compression load exceeds the calculated buckling load on the rod. Seismic Rod Brace Clamps shall be capable of easily attaching supplemental steel to the suspended threaded rod. It is easily installed after the rod is installed. Typically used with a minimum of three per rod when required.

**The VMC Group**

Headquarters: 113 Main Street • Bloomingdale, NJ 07403 | Houston: 11930 Brittmoore Park Drive • Houston, TX 77041

Phone: 973.838.1780 | Toll Free: 800.569.8423

[www.thevmcgroup.com](http://www.thevmcgroup.com)